


©2026

The Ultra Space Saver Squared has several steps for installation. Note that the single and double sided setups and parts are different. Make sure you follow the instructions according to the model you ordered.

Recommended Base Materials:


Solid concrete is the best base material for installation. Make sure nothing is underneath the base material that could be damaged by drilling (i.e. post-tension cable). Use the 3.75" wedge anchors that are included to install the rack into the concrete (wall anchors are 3").

Installation:

Sort out the parts to the rack and identify each of them accordingly. The 1" carriage bolts are for assembly of the rack and the 3.75" wedge anchors are for mounting the rack to the floor.


Reading your Dero designed layout

Ultra Space Saver Squared come in varying configurations, making it **very important** that you carefully **follow the layout provided by Dero** when installing the racks. If you do not follow the diagram, you may well end up short of parts. The length of each Ultra Space Saver Squared unit will be indicated in your layout like the example below.





Be sure to use the crossbar lengths indicated in your layout!

Single Sided Parts



Double Sided Parts





Wall Mounting Bracket (Wall Mounted Only): **SS-W**

©2026

TOOLS NEEDED


9/16” Wrench/Socket
3/8” or 1/2” Masonry Drill Bit (Depending on anchor type)
Tape Measure
Drill (Hammer drill recommended)
Hammer
Level
Marker or pencil
Pin-in-hex tool (provided)

NOTE

Before installing make sure the wall is strong enough to accommodate the rack fully loaded with bikes. Steel stud walls are not suitable for installation


Examples shown in these instructions represent 4-unit sections. Actual lengths may vary based on your space. Please follow any Dero provided layout closely when installing racks.

1




Lay out parts on the floor where unit is to be installed and be sure you have all necessary parts.

2




On crossbeams, Place a mark three inches from each end. This mark will show you how far to slide the crossbeam into the wall bracket.

3



Place first wall bracket on wall where you want to install the bike rack. The lowest hole of bracket should be 50” from the ground. Mark holes for drilling.


4



Drill Holes into wall, put the wall bracket back up and insert wall anchors through holes in bracket and set the anchors. For setting the anchors and diameter and depth of holes, follow instructions sent with the anchors. Make sure bracket is level.


©2026

5



Stagger height of arms

Thread 3/8” by 3/4” tightening bolts into holes in bracket. Insert crossbeams into bracket. Slide on arms and make sure arms are staggered. Use provided security tool to secure the arms with the set screws 16” apart on-center. Install end bracket, making sure crossbeams are level.




6

If installing more than one set of Ultra Space Saver Squared arms, continue from last installed wall bracket and repeat steps 3-5 above.

Optional Tire Stop

For the optional wall-mounted tire stop, anchor the unit to the wall so that the center of the tire stop bracket is 23” below the center of the bottom slot of the crossbeam bracket.



©2026


TOOLS NEEDED

9/16” Wrench/Socket
3/8” Masonry Drill Bit
Tape Measure
Drill (Hammer drill recommended)
Hammer


Examples shown in these instructions represent 4-unit sections. Actual lengths may vary based on your space. Please follow any Dero provided layout closely when installing racks.

1

Single Sided Rack
Mount at end of foot




Double Sided Rack
Mount at center holes



Measure out space. Attach feet to uprights with carriage bolts provided.


2



Place crossbeams into brackets. Finger-tighten bolts to hold crossbeams loosely in place.


©2026

3




Carefully slide first hanger arm onto crossbeams. For single-sided racks leave a 3” space between the hanger arm and mounting bracket. Use the provided security tool to tighten set screw to hold hanger arm in place.

4




Top view, correct double sided alignment (pegs face out)



Gently slide on remaining arms making sure to stagger height of each arm and tighten each set screw. Standard spacing between arms is 16”. For double sided model slide arms on opposite each other. Repeat until the crossbeams are full.


To avoid bicycle conflict on double sided units make sure each arm is installed to the right of its paired arm facing the opposite way (see diagram above).


5



Attach the second upright. Tighten bolts to secure crossbeams in brackets. For add-on units repeat steps.

6






Anchor rack to floor with 3.75” wedge anchors.

See diagrams on ensuing page for instructions on installing the optional cane stops.


©2026

1



Attach tire stop to uprights with supplied hardware.

2





Continue attaching tire stops if using a modular system.

©2026

Instructions for **floor mounted** racks

See diagrams below for guidance on installing the optional cane stops onto floor mounted racks. In a run of multiple sections of racks, the cane stops will overlap at the anchoring points.





A Cane Stop




x4

B 3/8” Nut



x6

C 3/8” Washer




x2


D 3/8” x 1.5” Carriage Bolt


©2026

Instructions for **wall mounted** racks

See diagrams below for guidance on installing the optional cane stops onto floor mounted racks. In a run of multiple sections of racks, the cane stops will overlap at the anchoring points.








Install cane stops in line with or within 4” back from the farthest protrusion of the rack from the wall.

INSTALLED





A 3/8” x 5” Wedge Anchor



B Cane Stop End




C Cane Stop



D Riser


©2026

1




Use 3/4” x 16” board as a substrate to mount the racks. White Melamine board works well.

2




Lay out the wall mounting brackets on the board and mark the (3) holes per bracket on the board. Drill at marks with a 1/2” drill and press 3/8”-16 Tee Nuts in the back of the board.

3




Place the board on the wall and attach with (3) 3/16” x 3” self-drilling screws at each metal stud. The center of the board should be 52” from the ground. 4” wood screws may be used for wood studs.

4



Attach the USS racks to the board with (3) 3/8”-16 x 1” bolts and washers at each wall mounting bracket.

If installing the optional tire stop, follow the same procedure, but with (2) self-drilling screws at each metal stud. Anchor the unit to the wall so that the center of the tire stop bracket is 23” below the center of the bottom slot of the crossbeam bracket.



Dero is not responsible for verifying installation surface and location. Installer assumes all liability for secure installation.

©2026